CD RECEIVER

KDC-7009/7060R/RY

SERVICE MANUAL

KENWOOD

© 1998-1 PRINTED IN JAPAN B51-7268-00 (N) 3027






Photo is KDC-7009



CONTENTS

BLOCK DIAGRAM	
CIRCUIT DESCRIPTION	4
ADJUSTMENT	6
PC BOARD	
SCHEMATIC DIAGRAM	
EXPLODED VIEW	
MECHANISM	23
UNIT	24
PARTS LIST	25
SPECIFICATIONS	

KDC-7009/7060R/RY BLOCK DIAGRAM



CIRCUIT DESCRIPTION

Microprocessor : μPD784215GF514 (IC1, X25-)

Terminal ddescription

No.	Pin name	Port name	I/O	Function	Active
1	P60/A16	TYPE0	1	Destination pin 0	
2	P61/A17	TYPE1	1	Destination pin 1	
3	P62/A18	TYPE2	1	Destination pin 2	
4	P63/A19	ST_TYPE0	1	IC2 Ver. 2 Destination pin 0	Default : Lo
5	P64/RD	ST_TYPE1	1	IC2 Ver. 2 Destination pin 1	Default : Lo
6	P65/WR	NC	0	Output open	
7	P66/WAIT	ANA_B	0	Spectrum analyzer frequency selection pin	
8	P67/ASTB	ANA_A	0	Spectrum analyzer frequency selection pin	
9	Vdd		-	Positive power supply pin	
10	P100/T15/T05	NC	0	Output open	
11	P101/T16/T06	SVR	0	Power IC reset pin	Power ON : Lo
12	P102/T17/T07	NC	0	Output open	
13	P103/T18/T08	P_MUTE	0	Power IC mute pin	Active : Hi
14	P30/TO0	ANT_CON	0	Antenna control pin	Active : Hi
15	P31/TO1	NC	0	Output open	
16	P32/TO2	DIMMER	1	Dimmer detection	Active : Lo
17	P33/TI1	P_CON	0	Power control pin	Active : Hi
18	P34/TI2	ACC_DED	1	ACC detection pin	ACC off : Hi
19	P35/TI00	REMO	1	Remote control input pin	
20	P36/TI01	P_ON	0	Microprocessor peripheral power supply pin	Active : Hi
21	P37/	BU_DED	1	Mute detection pin	Mute : Hi
22	TEST		-	Test pin	
23	P90	IC2_SDA	I/O	IC2, IC4, EEPROM data line	
24	P91	IC2_SCK	0	IC2, IC4, EEPROM clock line	
25	P92 .	MUTE	0	Mute pin	Active : Hi
26	P93	SW5	0	5V power supply pin	Active : Lo
27	P94	NC	0	Output open	
28	P95	CHCON2	0	Changer 2 control pin	Active : Lo
29	P120/RTP0	CHCON1	0	Changer 1 control pin	Active : Hi
30	P121/RTP1	CH_MUTE	1	Changer mute input pin	Mute request : Hi
31	P122/RTP2	REQH	0	Changer handshake request pin	Active : Lo
32	P123/RTP3	ILL_ON	0	Illumination output	Active : Hi
33	P124/RTP4	NC	0	Output open	47.5
34	P125/RTP5	CD_SW2	t	12cm CD detect	ON : Lo
35	P126/RTP6	CD_SW1	1	Loading SW detection	ON : Lo
36	P127/RTP7	M_DATAM	1	Data line from CD mechanism	
37	Vdd		-	Positive power supply pin	
38	X2		-	Main clock connection	
39	X1		-	Main clock connection	
40	Vss		-	GND pin	
41	XT2		-	Sub clock connection pin	
42	XT1		-	Sub clock connection pin	
43	RESET		- 1	Reset input pin	Active : Lo
44	P00/INTP0	CH_RST	0	Changer reset output pin	Active : Hi
45	P01/INTP1	R_CLK	1	RDS clock input pin	
46	P02/INTP2/NMI	REQC	1	Changer handshake request pin	Active : Lo
47	P03/INTP3	NC	0	Output open	
48	P04/INTP4	M_CLK	0	Clock line to CD mechanism	
49	P05/INTP5	M_DATAS	0	Data line to CD mechanism	

CIRCUIT DESCRIPTION

No.	Pin name	Port name	I/O	Function	Active
50	P06/INTP6	M_SRQ	I	Handshake request from CD mechanism	
51	AVdd		-	A/D analog power supply pin	
52	AVref0		-	A/D reference voltage input pin	
53	P10/ANI0	PHONE	1	PHONE detection pin	1V or less : PHONE,
					2.5V or greater : NAVI MUTE
54	P11/ANI1	SRM_SW1	1	SRM position detection pin	Open : Hi
55	P12/ANI2	NOISE	1	FM noise detection pin	
56	P13/ANI3	AMETER	1	FM S meter detection pin	
57	P14/ANI4	ANA X	1	Spectrum analyzer input pin	
58	P15/ANI5	ANA_Y		Spectrum analyzer input pin	
59	P16/ANI6	IF_MODE		K2I IF mode detection pin	Wide : Hi, Narrow : Lo
60	P17/ANI7	M_MUTE		Mute request from CD meshanism	MUTE : Lo
61	AVss	-	-	A/D GND pin	
62	P130/ANO0	M_CS	0	Handshake request to CD mrchanism	Handshake : Lo
63	P131/ANO1	M_RST	0	Reset to CD mechanism	RESET : Lo
64	AVref1		-	D/A reference voltage input pin	
65	P70/RxD2/SI2	DATAC	1 1	Data line from changer	
66	P71/TxD2/SO2	DATAH	0	Data line to changer	
67	P72/ASCK2/SCK2	CH_CLK	1/0	Changer clock line	
68	P20/R×D1/SI1	L_DATAL	1 7	Data line to LCD driver	
69	P21/TxD1/S01	L_DATAS	0	Data line from LCD driver	
70	P22/ASCK1/SCK1	L_CLK	0	LCD driver clock pin	_
71	P23/PCL	M_STOP	0	Stop request to CD mechanism	STOP : Lo
72	P24/BUZ	BEEP	0	Beep detection pin	Active : Hi
73	P25/SI0	PLL CE	0	PLL CE pin	Active . III
74	P26/SO0	PLL_DATA	0	PLL data input/output pin	
75	P27/SCK1	PLL_CLK	0	PLL clock pin	
76	P80/A0	CD_SW3	1	Down SW detection	ON : Hi
77	P81/A1	LO/EJ	1/0	Load/eject select	Load : L / EJ : Hi
78	P82/A2	MOSW	0	Sub motor control	Load : Hi / EJ : Lo
79	P83/A3	NC	0	Output open	2080 : 111 / 23 : 20
80	P84/A4	KEY_REQ	+ -	Key input request from LCD driver	Key : Hi
81	P85/A5	L_CE1	0	LCD driver CE pin	Key . III
82	P86/A6	L_INH	0	LCD driver reset pin	Reset : Lo
83	P87/A7	L_CE2	0	LCD driver CE pin	neset . Lo
84	P40/AD0	QUAL	1	RDS reception mode	
85	P41/AD1	R_DATA	+ 1	RDS data input pin	-
86	P42/AD2	SRM_SUB-	0	Panel motor control (SRM)	
87	P43/AD3	SRM_SUB+	0	Panel moter control (SRM)	
88	P44/AD4	SRM_DET	1	SRM mechanism detection pin	Mechanism : Lo, No mechanism : Hi
89	P45/AD5	SRM_SW2	 	SRM eject position detection pin	Startup : Eject position
90	P46/AD6	FM_SD	<u> </u>	FM SD input pin	Station : Hi, No station : Lo
91	P47/AD7	NC NC	0	Output open	Station . Th, 140 Station . Ed
92	P50/A8	AFC	0	Noise detection constant selection pin	Reception : Hi, Search : Lo
93	P51/A9	LO/DX	0	Local output pin	Local : Hi, Normal : Lo
94	P52/A10	WIDE	0	K2I forced wide output pin	Active : Hi
95	P53/A11	NQRROW	0	K2I forced narrow output pin	Active : Hi
96	P54/A12	AM+B	0	AM power supply pin	Active : Hi
97	P55/A13	FM+B	0	FM power supply pin	Active : Hi
98	P56/A14	NC	0	Output open	Active . I II
99	P57A15	NC	0	Output open	
100	Vss		-	GND pin	-


ADJUSTMENT

K,M type


No	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	TUNER (RECEIVER)	ALIGNMENT POINTS	ALIGN FOR	FIG.
FM SE	CTION						
1.		(C)					
		98.1MHz					
		1kHz, ±67kHz dev		FM			
	SEPARATION	Pilot : ±7.5kHz dev	(B)	98.1MHz	VR1	Separation : MAX	
		Selector : L or R					
		60dBμ (ANT input)					

E type

No	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	TUNER (RECEIVER)	ALIGNMENT POINTS	ALIGN FOR	FIG.
FM SI	ECTION						
1.		(C)				,	
		98.1MHz					
	CEDARATION	1kHz, ±40kHz dev	(D)	FM	VR1	Conquetion , MAY	
	SEPARATION	Pilot : ±6.0kHz dev	(B)	98.1MHz	VNI	Separation : MAX	
		Selector : L or R					
		60dBμ (ANT input)					



PC BOARD (COMPONENT SIDE VIEW)



	E SECTION REPORTED TO THE PROPERTY OF THE PROP
AUTO 64	
	Ici
20	A Description of the Control of the
40	24
027	CE CONTROL OF THE CON
	produce and account of the second of the sec
C8 C10	
37	48 6
36	3 2 2
	TC2
25	11111111111111111111111111111111111111
	P26 (06)

H- H- D8

X13-9140-10 (J74-0718-12)

S20 RESET


IC	Q	address
1		31
2		51
3		61
	1	3J
	2	61
	_	

(X13-9140-10)

1		31	menimon
2		51	MANAGEM
3		61	NOMBORO
	1	3J	Mentionerin
	2	61	1004644000
	3	5J	AND BROWN
	4	5J	NACONING AND ADDRESS OF THE PERSON NACON INC.
	5	21	Section Sections
	6	6J	Posteropeope

PC BOARD (FOIL SIDE VIEW)


X13-9140-10 (J74-0718-12)




TC3

(X13-9140-10)

IC	Q	address
1		3L
2		5L
3		6L
	1	3K
	2	6L
	3	5K
	4	5K
	5	2L
	6	6K



PC BOARD (COMPONENT SIDE VIEW)




(X32-4280-00)

IC	1	2	3	4	5	6						
Q							1	2	3	4	5	6
address	4V	5W	ЗХ	2X	4W	5W	4V	4X	4W	4W	4X	5X

Refer to the schematic diagram for the values of resistors and capacitors.


PC BOARD (FOIL SIDE VIEW)



(X32-4280-00)


(-	-						MARKET TO SERVICE AND ADDRESS OF THE PARTY O	ATTENDED TO STATE OF THE PARTY
IC	1	2	3	4	5	6						
Q							1	2	3	4	5	6
address	4AC	5AB	ЗАА	2AA	4AB	5AB	4AC	4AA	4AB	4AB	4AA	5AB

Refer to the schematic diagram for the values of resistors and capacitors.



caution: I components parts (refer component leakage-cur carried out from the su turned to the

 DC voltage ance voltage variations units.



NJM2903M NJM4565M-TE2 NJM4565MD 2SD2396 TC74HC02AF DTA114EK DTA124EK PST9130NR DTC124TK DAN202K DTC143TK DTC114EK DTC144EK DTC114TK 2SA1362 2SC2412K 2SD2114K DTC114YK DTC124EK 2SB1184 M5237ML TA78L05F 2SB1277 DA204K AN8806SB 2SB1443

M


0


CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). △ Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.


2SA1037K

 DC voltages are as measured with a high impedance voltmeter. Values may vary slightly due to variations between individual instruments or/and units.

KDC-7009/7060R/RY








CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). △ Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.

 DC voltages are as measured with a high impedance voltmeter. Values may vary slightly due to variations between individual instruments or/ and units.

KDC-7009/7060R/RY




CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). ⚠ Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.


DC voltages are as measured with a high impedance voltmeter.
 Values may vary slightly due to variations between individual instruments or/and units.

KDC-7009/7060R/RY

EXPLODED VIEW (MECHANISM)



EXPLODED VIEW (UNIT)



KDC-7009/7060R/RY KDC-7009/7060R/RY **PARTS LIST**

PARTS LIST

* New Parts

Ref. No.

206

207

218

1 D

1 D

1 D

1 C

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht gelie Parts No.

A10-4428-22 A10-4313-62

A10-4314-62

A10-4315-04 A10-4317-04

A10-4319-04

A10-4321-04

1D | A10-4353-53 3C | * A22-2272-03

2C * A46-1279-02

2C * B03-3027-03 1C * B07-2117-02

1C * B07-2118-03 3C * B10-1799-01 3C * B10-2804-01

B46-0100-50 B46-0172-13

B46-0612-14

B58-1255-04 B58-1278-04

B58-1282-04

B58-1283-04 B64-1179-00

864-1181-00

B64-1183-00

B64-1184-00

B64-1185-00

D10-4067-14

D10-4139-13

D10-4140-13

D13-1302-64

D13-1306-14

D13-1348-03

D13-1349-04 D13-1350-04

D13-1312-24

D13-1320-13

D13-1321-13 D14-0676-04

D14-0678-04

D14-0680-34

D14-0681-34 E30-4576-05

E30-4549-05 E30-4551-05

E30-4577-05

werden nie	cht geliefert.	1			N	1	KDC-7009/7060R/RY
ts No.	Description		Ref. I	Vo.	N e W	Parts No.	Description
	09/7060R/RY]	240 244	1C 2D		F09-1244-04 F29-0049-05	SHEET INSULATING COVER
128-22 313-62 314-62 315-04 317-04	CHASSIS ASSY CHASSIS ASSY CHASSIS ASSY CHASSIS CALKING ASSY CHASSIS CALKING ASSY	A	F1 246 250	2D 1D 2D		F52-0006-05 G01-2818-24 G11-1733-04	FUSE(MINI BLADE TYPE) EXTENSION SPRING CUSHION
319-04 321-04 353-53 272-03	CHASSIS CALKING ASSY CHASSIS CALKING ASSY CHASSIS ASSY SUB PANEL ASSY REAR COVER		- - -			H10-4560-02 H13-1681-04 H21-1118-04 H25-0329-04 H25-0337-04	POLYSTYRENE FOAMED FIXTURE CARTON BOARD PROTECTION SHEET PROTECTION BAG(280X450X0.03) K2E5 PROTECTION BAG(180X300X0.03)
110-12 64-02 69-02	TOP PLATE PANEL ASSY K2 PANEL ASSY E4E5		-		* *		PROTECTION BAG(100 X 300 X 0.03) E 4 E 5 PROTECTION BAG(280 X 450 X 0.03)
27-03 17-02 18-03 799-01 804-01	DRESSING SEAL		253 254 255 258 260	1C 1C 1C 1D	*	J19-4720-04 J19-4721-04 J21-7934-03 J31-1035-14 J54-0606-04	BRACKET(L) K2 BRACKET(R) K2 MOUNTING HARDWARE ASSY COLLAR STAY K2
00-50 72-13 12-14 255-04 278-04	WARRANTY CARD K2E4 QUESTIONAIRE CARD K2 ID CARD E4E5 CAUTION CARD (SRM, zt " N 7 2) K2E4 CAUTION CARD K2E4		FPC1 FPC2 FPC3	3D 1D 2C		J84-0061-33 J84-0062-23 J84-0066-03	FLEXIBLE PRINTED WIRING BOARD FLEXIBLE PRINTED WIRING BOARD FLEXIBLE PRINTED WIRING BOARD
82-04 83-04 79-00 81-00 82-00	CAUTION CARD(SRM,zt~n#s) E5 CAUTION CARD E5 INSTRUCTION MANUAL(E,F,S) K2 INSTRUCTION MANUAL(E,F) E4 INSTRUCTION MANUAL(G,D,I) E4		261 262 263 264 265	3C 3C	*	K25-0874-03 K25-0851-03 K25-0852-03	KNOB (AUD) KNOB (ATT) KNOB (1-6) KNOB (FM/AM) KNOB (SRC)
83-00 84-00	INSTRUCTION MANUAL(S,P) E4 INSTRUCTION MANUAL(E,R,PL) E5	1	266 267	3C	*	K25-0876-03	KNOB (DISP) KNOB (VOL)
85-00 167-14 39-13 40-13	INSTRUCTION MANUAL(CN, H, CR) E5 LEVER ARM ASSY ARM ASSY GEAR ASSY		270 271 A B C	1 C 1 C 1 D 2 C 3 C		N99-1652-05 N09-1885-05 N83-3005-46 N67-3005-46 N30-2003-46	SCREW SET K2 SEMS (MACHINE SCREW) E4E5 PAN HEAD TAPTITE SCREW PAN HEAD SEMS SCREW PAN HEAD MACHINE SCREW
306-14 348-03 349-04 350-04	GEAR GEAR GEAR GEAR GEAR		D E F G H	1 D 3 C 2 C 1 D 3 C		N09-4184-05 N80-2005-46 N80-2008-46 N88-2006-45 N35-2003-45	MACHINE SCREW (M2X2 29320003) PAN HEAD TAPTITE SCREW PAN HEAD TAPTITE SCREW FLAT HEAD TAPTITE SCREW BINDING HEAD MACHINE SCREW
13-04 120-13 121-13 176-04	GEAR GEAR ASSY GEAR ASSY ROLLER ROLLER ASSY		J K M P Q	1D 2D 3D 1D 1D		N19-2062-04 N19-2022-04 N35-2004-46 N09-4185-05 N19-2058-04	FLAT WASHER FLAT WASHER BINDING HEAD MACHINE SCREW MACHINE SCREW (M2X2 #5 152 2) FLAT WASHER
78-04 80-34 81-34	ROLLER ROLLER		R	1 D 1 D	***************************************	N19-2103-04 N09-4218-05	FLAT WASHER MACHINE SCREW (M2X 3)
76-05	CORD WITH PINPLUG		SW271	10		S68-0829-05	PUSH SWITCH
49-05 51-05 77-05	DC CORD K2 DC CORD E4E5 CORD WITH DIN CONNECTOR		272 M272	1 D 1 D		T90-0512-05 T42-0752-14	ANTENNA ADAPTOR E4E5
			ME1	20		X92-3120-00	MECHANISM ASSY

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

SWITCH UNIT (X13-9140-10) ELECTRIC UNIT (X25-796X-XX)

E4E5

50WV

25WV

50WV

6.3WV

10WV

16WV

16WV

50WV

25WV 10WV

6.3WV

10WV E4E5

50WV

10WV

16WV

10WV

E4E5

E4E5

E4E5

E4E5

E4E5

E4E5

E4E5

E4E5

50WV 50WV

Teile ohne	Pa	arts No. werden nic	cht geliefert.							ELECTR	C OIVIT (A	123
Ref. No.	N e w	Parts No.	De	scription		Ref	No.	N e N	Parts No.		Description	on
		SWITCH UN	IIT (X13-9140-1	10)		C12			CK73FB1H103K	CHIP C	0.010UF	K
D1 -7 D8 -10 D11 ED1 2C		B30-1349-05 B30-1515-05 B30-1516-05 B38-0687-05	LED LED LED LIQUID CRYST	AL		C13 C14 C25 C27	,26		CK73FB1H223KTA C90-2608-05 CK73FB1E473KTA C90-2598-05	CHIP C ELECTRO CHIP C ELECTRO	0.022UF 1.0UF 0.047UF 3.3UF	K 50 K 25
C1 C2 ,3 C4 C6 C7		CK73FB1H821K CK73FB1E473KTA CK73FB1H103K CK73FB1C225K CK73FB1H821K	CHIP C CHIP C CHIP C CHIP C	820PF 0.047UF 0.010UF 2.2UF 820PF	K K K K	C28 C29 C30 C31 C33	,32		CK73FB1E683KTA C90-2602-05 CK73FB1H102K CK73FB1H103K CE04CW0J470M	CHIP C ELECTRO CHIP C CHIP C ELECTRO	0.068UF 0.10UF 1000PF 0.010UF 47UF	K 50 K 6.
C8 ,9 C10 C11 -13		CK73FB1E473KTA CK73FB1H103K CK73FB1C104K	CHIP C CHIP C	0.047UF 0.010UF 0.10UF	K K K	C34 C35 C37 C38 C40	, 36		CK73FB1H103K CC73FCH1H220J CK73EB1C105K CK73FB1H472K CK73FB1H222K	CHIP C CHIP C CHIP C CHIP C	0.010UF 22PF 1.0UF 4700PF 2200PF	K J K K
303 2C CN1	*	E29-1541-04 E40-9407-05	CONDUCTIVE R			C50			CK73FB1C104K	CHIP C	0.10UF	K
CP1 CP2 R8 R9		R90-1016-05 R90-0725-05 RK73FB2A683J RK73FB2A102J	MULTIPLE RES MULTI-COMP CHIP R CHIP R	1STOR 1K X2 68K J 1.0K J	1/10W 1/10W	C54 C55 C56 C57			CC73FCH1H121J CK73FB1C823K CK73FB1C104K CK73EB1C105K	CHIP C CHIP C CHIP C	120PF 0.082UF 0.10UF 1.0UF	J K K K
R10 R11 R12 R13		RK73FB2A101J RK73FB2A683J RK73FB2A473J RK73EB2B331J	CHIP R CHIP R CHIP R CHIP R	100 J 68K J 47K J 330 J	1/10W 1/10W 1/10W 1/8W	C58 C59 C60 C61 C65	,66		CK73FB1H183KTA CK73FB1H103K CE04CW1A101M C90-2608-05 C90-2610-05	CHIP C CHIP C ELECTRO ELECTRO ELECTRO	0.018UF 0.010UF 100UF 1.0UF 2.2UF	K K 10 50
R14 ,15 R17 -20		RK73EB2B471J RK73EB2B331J	CHIP R CHIP R	470 J 330 J	1/8W 1/8W	C67 C81	,68		C90-2597-05 C90-2597-05	ELECTRO ELECTRO	10UF 10UF	16 16
R21 R22 R23 R24 ,25		RK73EB2B301J RK73EB2B621J RK73EB2B241J RK73FB2A273J	CHIP R CHIP R CHIP R CHIP R	300 J 620 J 240 J 27K J	1/8W 1/8W 1/8W 1/10W	C95 C99 C100	-98		CK73FB1C124K C90-2606-05 C90-2598-05	CHIP C ELECTRO ELECTRO	0.12UF 0.47UF 3.3UF	K 50 25
R26		RK73FB2A334J	CHIP R	330K J	1/10W	C101	2		CE04CW1A101M C90-2597-05	ELECTRO ELECTRO	100UF 10UF	10 16
S1 -12 S13 -20 S21		\$70-0839-05 \$70-0813-05 \$70-0821-05	TACT SWITCH TACT SWITCH TACT SWITCH			C111	2,113	-	CK73FB1H153KTA CE04CW0J470M C90-2608-05	CHIP C ELECTRO ELECTRO	0.015UF 47UF 1.0UF	К 6. 50
IC1 IC2 IC3 Q1 ,2 Q1 ,2		LC75883E LC75833E PAS-B06B1FE DTA114EK UN2111	MOS-IC MOS-IC ANALOGUE IC DIGITAL TRAN DIGITAL TRAN			C114 C115 C117 C118	3,116		CE04CW0J470M CK73FB1C224K C90-2594-05 CK73FB1H103K C90-2594-05	ELECTRO CHIP C ELECTRO CHIP C ELECTRO	47UF 0.22UF 10UF 0.010UF 10UF	6. K 10 K 10
Q3 -5 Q6		2SD2114K DTC114YK	TRANSISTOR DIGITAL TRAN	SISTOR		C120	,121		CC73FCH1H100D CC73FCH1H271J	CHIP C	10PF 270PF	D J
Q6		UN2214	DIGITAL TRAN	SISTOR		C123	3		CK73FB1H103K C90-2595-05	CHIP C ELECTRO	0.010UF 4.7UF	K 16
C1		C90-2856-05	ELECTRO	3900UF	16WV	C125		1	CK73FB1H103K	CHIP C	0.010UF	K
C2 C3 C4 C5		CK73FB1H103K C90-2926-05 CK73FB1H103K C90-2594-05	CHIP C ELECTRO CHIP C ELECTRO	0.010UF 220UF 0.010UF 10UF	K 16WV K 10WV	C126 C128 C129 C130 C131	}		C90-2594-05 CK73FB1H103K CK73FB1H153KTA C90-2594-05 CC73FCH1H471J	CHIP C CHIP C ELECTRO CHIP C	10UF 0.010UF 0.015UF 10UF 470PF	10 K K 10 J
C6 C7 C8 C9 C10		CE04CW0J101M CK73EB1C105K CE04CW1A221M CE04CW1C470M CE04CW1A101M	ELECTRO CHIP C ELECTRO ELECTRO ELECTRO	100UF 1.0UF 220UF 47UF 100UF	6.3WV K 10WV 16WV 10WV	C132 C133 C134 C136 C137	,135		CC73FCH1H121J CC73FCH1H060D CC73FSL1H122J CC73FCH1H180J CC73FCH1H471J	CHIP C CHIP C CHIP C CHIP C	120PF 6.0PF 1200PF 18PF 470PF	J D J J
												_

K2:KDC-7009

E4:KDC-7060R

1 C 1 D 1 D 2 D 1 D

2D 2D 2D 1D

1 D 1 D 3 C

1 D

3 D

3D

1 C 1 C

236

E5:KDC-7060RY

 $\underline{\mathbb{A}}$ indicates safety critical components.

K2:KDC-7009 E4:KDC-7060R

E5:KDC-7060RY

KDC-7009/7060R/RY KDC-7009/7060R/RY **PARTS LIST**

* New Parts

Ref. No.

C138 C139 C140 C141 C142

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-796X-XX)

	New	Parts No.	Description	1	Ref. No.	N e w	Parts No.			<u> </u>		
_	w	raits ivo.	Description		nei. No.	w	Farts IVO.		Descr	ipti	on 	
		CC73FCH1H820J CC73FSL1H102J CK73FB1H223KTA CC73FSL1H222J CK73FB1H822K	CHIP C 82PF J E4E5 CHIP C 1000PF J E4E5 CHIP C 0.022UF K E4E5 CHIP C 2200PF J E4E5 CHIP C 8200PF K E4E5		R16 R17 R18 R19 R20		RK73EB2B103J RK73FB2A223J RK73FB2A473J RK73FB2A102J RK73EB2B104J	CHIP R CHIP R CHIP R CHIP R	10K 22K 47K 1.0K 100K	J J J J	1/8W 1/10W 1/10W 1/10W 1/8W	K2 E4E5 E4E5 E4E5
		CK73FB1H103K CC73FCH1H471J CK73FB1H103K CE04CW1A101M CK73FB1E273KTA	CHIP C 0.010UF K CHIP C 470PF J E4E5 CHIP C 0.010UF K ELECTRO 100UF 10WV CHIP C 0.027UF K		R34 R35 R36 R37 R38		RK73FB2A472J R92-0366-05 RK73FB2A223J RK73FB2A472J R92-0365-05	CHIP R CHIP R CHIP R CHIP R CHIP R	4.7K 560 22K 4.7K 1.0K	J J J J	1/10W 1W 1/10W 1/10W 1/2W	K2
		CK73EB1C105K CK73FB1H103K CK73FB1H103K E40-3243-05	CHIP C 1.0UF K E4E5 CHIP C 0.010UF K CHIP C 0.010UF K		R39 R40 R41 R42 R43 -45		RK73FB2A223J R92-0365-05 RK73EB2B472J RK73EB2B102J	CHIP R CHIP R CHIP R CHIP R	22K 1.0K 4.7K 1.0K	J J J	1/10W 1/2W 1/8W 1/8W	
		E40-3237-05 E40-3252-05 E40-3261-05 E40-9550-05	PIN ASSY PIN ASSY PIN ASSY FLAT CABLE CONNECTOR FLAT CABLE CONNECTOR		R46 -48 R49 R50 ,51 R52 R53		RK73EB2B470J RK73EB2B102J RK73FB2A104J RK73FB2A123J RK73FB2A562J RK73FB2A223J	CHIP R CHIP R CHIP R CHIP R CHIP R CHIP R	1.0K 100K 12K 5.6K 22K	J J J J	1/8W 1/8W 1/10W 1/10W 1/10W	
D		E40-5029-05 E58-0836-05 E30-4575-05 L40-4795-34	FLAT CABLE CONNECTOR RECTANGULAR RECEPTACLE CORD WITH PLUG (ANT) SMALL FIXED INDUCTOR		R54 R55 ,56 R57 R58		RD14DB2H332J RK73EB2B473J RK73FB2A622J RK73FB2A473J	SMALL-RD CHIP R CHIP R CHIP R		J J J	1/2W 1/8W 1/10W	
		L40-4795-34 L40-4795-34 L33-1039-05 L40-4791-17	SMALL FIXED INDUCTOR E4E5 SMALL FIXED INDUCTOR K2 LINE FILTER COIL SMALL FIXED INDUCTOR(4.7UH,K)		R59 R60 R61 R63		RK73FB2A684J RK73FB2A104J RK73FB2A104J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R	680K 100K 100K 100K	j j j	1/10W 1/10W 1/10W 1/10W	K2 E4E5 K2
		L78-0574-05 L78-0533-05 L77-2002-05	RESONATOR RESONATOR (32.768KHZ) CRYSTAL RESONATOR E4E5		R63 ,64 R65		RK73FB2A104J RK73FB2A104J RK73FB2A222J	CHIP R	100K 100K	J	1/10W 1/10W 1/10W	E4E5
D D D		N83-3005-46 N83-3020-46 N64-3010-46 N30-3005-46	PAN HEAD TAPTITE SCREW PAN HEAD TAPTITE SCREW PAN HEAD SEMS SCREW PAN HEAD MACHINE SCREW		R67 R68 R69 R70		RK73FB2A472J RK73FB2A225J RK73FB2A222J RK73FB2A102J	CHIP R	4.7K	J J J	1/10W 1/10W 1/10W 1/10W	
		R90-0725-05 R90-0724-05 R90-0725-05 R90-0725-05 R90-0725-05	MULTI-COMP 1K X2 MULTI-COMP 1K X4 MULTI-COMP 1K X2 K2 MULTI-COMP 1K X2 E4E5 MULTI-COMP 1K X2 K2		R71 R72 ,73 R74 R75 R76		RK73FB2A472J RK73FB2A562J RK73FB2A223J RK73FB2A222J RK73FB2A470J			J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	
		RK73FB2A223J RK73FB2A101J RK73FB2A223J RK73FB2A472J RK73EB2B221J	CHIP R 22K J 1/10W CHIP R 100 J 1/10W CHIP R 22K J 1/10W CHIP R 4.7K J 1/10W CHIP R 220 J 1/8W		R77 R78 R79 ,80 R81 R82 ,83		RK73FB2A104J RK73FB2A470J RK73FB2A222J RK73FB2A102J RK73FB2A104J	CHIP R CHIP R CHIP R	47 2.2K 1.0K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	K2
		RK73FB2A153J R92-2046-05 R92-2041-05 RK73FB2A223J R92-2063-05	CHIP R 15K J 1/10W CHIP R 4.3K D 1/10W CHIP R 47K D 1/10W CHIP R 22K J 1/10W CHIP R 680 J 1/2W		R83 R84 -87 R89 R90 R91		RK73FB2A104J RK73FB2A102J RK73FB2A104J RK73FB2A222J RK73FB2A104J	CHIP R CHIP R CHIP R	2.2K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E4E5 E4E5 K2
		RK73FB2A152J RK73FB2A102J RK73FB2A471J RK73FB2A104J RK73EB2B103J	CHIP R 1.5K J 1/10W CHIP R 1.0K J 1/10W CHIP R 470 J 1/10W CHIP R 100K J 1/10W CHIP R 10K J 1/8W E4E5		R92 R93 R94 R95 R97		RK73FB2A102J RK73FB2A222J RK73FB2A223J R92-2041-05 RK73FB2A102J	CHIP R CHIP R CHIP R	2.2K 22K 47K	J J J D J	1/10W 1/10W 1/10W 1/10W 1/10W	E4E5

K2:KDC-7009 E4:KDC-7060R

E5:KDC-7060RY

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-796X-XX)

Ref. No.	New	Parts No.		Descript	tion		Ref. No.	N e w	Parts No.	Description	
R99 ,100 R101 R102,103 R104 R105-108		RK73FB2A102J RK73FB2A104J RK73FB2A470J RK73FB2A104J RK73FB2A222J	CHIP R 10 CHIP R 40 CHIP R 10	.OK J OOK J 7 J OOK J .2K J	1/10W 1/10W 1/10W 1/10W 1/10W		R222 R223 R224 R225 R226		RK73FB2A272J RK73FB2A333J RK73FB2A153J RK73FB2A103J RK73FB2A562J	CHIP R 2.7K J 1/10W CHIP R 33K J 1/10W CHIP R 15K J 1/10W CHIP R 10K J 1/10W CHIP R 5.6K J 1/10W	E4E5 E4E5 E4E5 E4E5 E4E5
R110,111 R112,113 R114 R115-117 R116,117		RK73FB2A104J RK73FB2A222J RK73FB2A164J RK73FB2A102J RK73FB2A102J	CHIP R 2 CHIP R 1 CHIP R 1	00K J .2K J 60K J .0K J	1/10W 1/10W 1/10W 1/10W 1/10W	K2 E4E5 E4E5 K2	R227 R228 R229 R230 R231		RK73FB2A103J RK73FB2A104J RK73FB2A103J RK73FB2A222J RK73FB2A562J	CHIP R 10K J 1/10W CHIP R 100K J 1/10W CHIP R 10K J 1/10W CHIP R 2.2K J 1/10W CHIP R 5.6K J 1/10W	E4E5 E4E5 E4E5 E4E5
R134-136 R137-139 R140 R141,142 R145		RK73FB2A104J RK73FB2A222J RK73EB2B472J RK73FB2A104J RK73FB2A472J	CHIP R 2 CHIP R 4 CHIP R 1	00K J .2K J .7K J 00K J .7K J	1/10W 1/10W 1/8W 1/10W 1/10W		R232 R233 R234 R235 R236		RK73FB2A272J RK73FB2A223J RK73EB2B102J RK73FB2A223J RK73EB2B102J	CHIP R 2.7K J 1/10W CHIP R 22K J 1/10W CHIP R 1.0K J 1/8W CHIP R 22K J 1/10W CHIP R 1.0K J 1/8W	
R147 R150 R151,152 R153,154 R155,156		RK73FB2A472J RK73FB2A332J RK73FB2A102J RK73FB2A361J RK73FB2A472J	CHIP R 3. CHIP R 1. CHIP R 3.	.7K J .3K J .0K J 60 J .7K J	1/10W 1/10W 1/10W 1/10W 1/10W		R237 VR1 W1 -15 W1 -17 W20 -23		RK73FB2A105J R32-0229-05 R92-2052-05 R92-2052-05 R92-2052-05	CHIP R 1.0M J 1/10W SEMIFIXED VARIABLE RESISTO CHIP R 0 J 1/10W CHIP R 0 J 1/10W CHIP R 0 J 1/10W	E4E5 RE4E5 E4E5 K2 K2
R157,158 R159,160 R161,162 R163,164 R181-184		RK73FB2A223J RK73FB2A361J RK73FB2A472J RK73FB2A223J RK73FB2A472J	CHIP R 30 CHIP R 4. CHIP R 22	2K J 60 J .7K J 2K J .7K J	1/10W 1/10W 1/10W 1/10W 1/10W		W21 ,22 W24 PH1		R92-2052-05 R92-2052-05 T95-0231-05	CHIP R 0 J 1/10W CHIP R 0 J 1/10W OPTO ISOLATOR	E4E5 E4E5
R185 R186 R187 R188 R189,190		RK73FB2A154J RK73FB2A431J RK73FB2A751J RK73FB2A183J RK73FB2A101J	CHIP R 43 CHIP R 75 CHIP R 18	50K J 30 J 50 J 8K J 00 J	1/10W 1/10W 1/10W 1/10W 1/10W		D1 D2 D2 D3 D4		RM10ZLF AM01Z ERA15-01 MA4056(N)-M MA4082(N)-L	DIODE DIODE DIODE ZENER DIODE ZENER DIODE	
R191 R192 R193,194 R195 R196		RK73FB2A223J RK73FB2A103J RK73EB2B100J RK73EB2B4R7J RK73EB2B104J	CHIP R 10 CHIP R 10 CHIP R 4.	2K J 0K J 0 J .7 J 00K J	1/10W 1/10W 1/8W 1/8W 1/8W		D5 D6 D6 D9 ,10 D11 ,12		MA4110-L HZM4.7NB2 MA3047-M DA204K AM01Z	ZENER DIODE ZENER DIODE ZENER DIODE DIODE DIODE	E4E5 E4E5 K2
R197 R198,199 R200 R202 R203		RK73FB2A222J R92-2021-05 RK73EB2B222J RK73FB2A682J RK73FB2A152J	CHIP R 2. CHIP R 2. CHIP R 6.	.2K J .2 J .2K J .8K J	1/10W 1/2W 1/8W 1/10W 1/10W	E4E5 E4E5 E4E5	D11 ,12 D12 D12 D13 D13		ERA15-01 AM01Z ERA15-01 DAP202K MA152WA	DIODE DIODE DIODE DIODE	K2 E4E5 E4E5
R204 R205 R206 R207 R208		RK73FB2A104J RK73FB2A222J RK73FB2A473J RK73FB2A222J RK73FB2A333J	CHIP R 2. CHIP R 47 CHIP R 2.	00K J .2K J 7K J .2K J 3K J	1/10W 1/10W 1/10W 1/10W 1/10W	E4E5 E4E5 E4E5 E4E5 E4E5	D14 D14 D15 -18 D19 ,20 D21		DAN202K MA152WK MA3062WA MA4056(N)-M DAN202K	DIODE DIODE ZENER DIODE ZENER DIODE DIODE	
R209 R210 R211 R212 R213		RK73FB2A392J RK73FB2A105J RK73FB2A224J RK73FB2A473J RK73FB2A103J	CHIP R 1.	.9K J .0M J 20K J 7K J	1/10W 1/10W 1/10W 1/10W 1/10W	E4E5 E4E5 E4E5	D21 D23 ,24 D25 -27 D25 -27 D28 ,29		MA152WK RD6.8MW DAP202K MA152WA RD6.8MW	DIODE ZENER DIODE DIODE DIODE ZENER DIODE ZENER DIODE	į
R214 R215 R216 R217-220 R221		RK73FB2A153J RK73FB2A913J RK73EB2B220J RK73FB2A103J RK73FB2A823J	CHIP R 15 CHIP R 91 CHIP R 22 CHIP R 10 CHIP R 82	1K J 2 J 0K J	1/10W 1/10W 1/8W 1/10W 1/10W	E4E5 E4E5 E4E5	D31 D31 D33 D34 D34		DAN202K MA152WK DSP-301N-A21F DAN202K MA152WK	DIODE DIODE DIODE BIODE DIODE	E4E5 E4E5
			_								

K2:KDC-7009 E4:KDC-7060R E5:KDC-7060RY

R1 R2 R3 R4 R5

R6 R7 R8 R9 R10

PARTS LIST

KDC-7009/7060R/RY KDC-7009/7060R/RY **PARTS LIST**

* New Parts

Ref. No.

D35 -43

IC1 IC2 IC3 IC4

IC6

IC7 IC8 IC9

IC17

IC18 IC19

Q2 Q2

Q3

Q5

Q6 Q6

Q7

89 Q9 Q9

Q10

Q12 Q12

921 922 922

Q23 Q24

925

Q27 Q28 ,29 Q28 ,29 Q30 Q30

933 934 -37

Q34 -37 Q38 Q38 Q39 ,40

Q39

Q31 Q31

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

DIODE MI-COM IC

ANALOGUE IC

ANALOGUE IC

ANALOGUE IC

ANALOGUE IC

ANALOGUE IC

TRANSISTOR TRANSISTOR

TRANSISTOR

TRANSISTOR

TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR

TRANSISTOR TRANSISTOR TRANSISTOR

TRANSISTOR

TRANSISTOR TRANSISTOR

IC(COMPARATOR X2) ANALOGUE IC TRANSISTOR

TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR

DIGITAL TRANSISTOR

DIGITAL TRANSISTOR DIGITAL TRANSISTOR

DIGITAL TRANSISTOR DIGITAL TRANSISTOR

DIGITAL TRANSISTOR

DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR

DIGITAL TRANSISTOR

DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR

DIGITAL TRANSISTOR DIGITAL TRANSISTOR

DIGITAL TRANSISTOR

DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR

TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR

DIGITAL TRANSISTOR

DIGITAL TRANSISTOR

CUSTOM IC

IC(VOLTAGE REGULATOR)

Description

E4E5 E4E5

K2

E4E5

Teile ohne Parts No. werden nicht geliefert. Parts No.

UPD784215GF514

TDA7461D

TDA7386

KKZ06F TC74HC02AF BA6287F

PST9130NR

TDA7479D

NJM2903M

25C2412K 25D601A

2SA1037K

2SB1443 DTC114YK

UN2214

2SD2396 DTA124EK UN2112 DTC144EK

UN2213

2SB1184 2SC2412K 2SD601A

DTC144EK UN2213

2SB1277(Q,R) DTC114EK

2SB1277(Q,R) 2SA1037K

DTA124EK

UN2112 DTC114EK

UN2211 DTA124EK

UN2112 2SC2412K 2SD601A

DTA124EK UN2112

DTC144EK UN2213

DTC124EK

UN2212 2502412K

2SD601A DTC144EK

UN2213 DTC143TK

UN2216

NJM4565M-TE2 2SB1565F(E,F)

2SB1565F(E,F)

ELECTRIC UNIT (X25-796

	. IN	II _	CD PLAYER UNIT (X32	1200 00
Ref. N	No.	Parts No.	Description	
Q41 Q41 Q42 Q42 Q43		DTC124TK UN2217 25C2412K 25D601A DTC114TK	DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	E4E5 E4E5 E4E5 E4E5 E4E5
Q43 Q44 Q44 Q45,		UN2215 DTA124EK UN2112 DTC124EK UN2212	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	E4E5 E4E5 E4E5 E4E5
Q48 Q49 Q49 Q50 Q51		2SB1277(Q,R) DTC124EK UN2212 2SB1277(Q,R) DTC124EK	TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	
Q51 TH1		UN2212 PT722A80C	DIGITAL TRANSISTOR POSITIVE RESISTOR	
A 1 A 1	3D 3D	W02-3119-05 W02-3123-05	FM/AM FRONT-END FM/AM FRONT-END	K2 E4E5
		CD PLAYER (JNIT (X32-4280-00)	
C1 , C3 , C5 C6 C7	2 4	CK73EB1C105K C92-0509-05 CC73FCH1H22OJ CC73FCH1H02OC CK73FB1C104K	CHIP C 1.0UF CHIP-TAN 10UF CHIP C 22PF CHIP C 2.0PF CHIP C 0.10UF	K 6.3WV J C K
C8 C9 C10 , C12 C13	11	CK73EB1C105K CC73FCH1H101J CK73FB1H682K CK73FB1H222K CK73FB1E273KTA	CHIP C 1.0UF CHIP C 100PF CHIP C 6800PF CHIP C 2200PF CHIP C 0.027UF	К Ј К К
C14 C15 C16 C17 C18		CK73FB1H472K CK73FB1E473KTA CC73FCH1H101J CK73FB1H222K CC73FCH1H391J	CHIP C 4700PF CHIP C 0.047UF CHIP C 100PF CHIP C 2200PF CHIP C 390PF	К К К К Ј
C19 , C21 C22 C23 C24	20	CK73FB1C104K C92-0509-05 CK73FB1C104K CK73FB1H102K CK73FB1H223KTA	CHIP C 0.10UF CHIP-TAN 10UF CHIP C 0.10UF CHIP C 1000PF CHIP C 0.022UF	K 6.3WV K K K
C25 C26 C27 C28 C31		CK73FB1H123K CK73FB1C104K CC73FCH1H101J CK73EB1C105K CK73EB1C105K	CHIP C 0.012UF CHIP C 0.10UF CHIP C 100PF CHIP C 1.0UF CHIP C 1.0UF	К К Ј К К
C41 C42 C43 C44 C45		C92-1335-05 CK73EB1H104K CK73FB1H123K CK73FB1C104K CK73FB1H223KTA	ELECTRO 4.7UF CHIP C 0.10UF CHIP C 0.012UF CHIP C 0.10UF CHIP C 0.022UF	16WV K K K K
C51 C53 C54 C55,	56	CK73EB1C105K C92-0509-05 CK73FB1C104K CK73EB1C105K	CHIP C 1.OUF CHIP-TAN 10UF CHIP C 0.10UF CHIP C 1.OUF	K 6.3WV K K

0V VV	Parts without Parts No. are not supplied.
6X-XX)	Les articles non mentionnes dans le Parts No. ne sont pas fournis.

* New Parts

Teile ohne Parts No. werden nicht geliefert.

Ref. No.	N e Parts No.	Description
C57 ,58 C61 ,62 C63 ,64 C65 ,66 C101	CK73FB1C224K CC73FCH1H471J CC73FCH1H680J CK73FB1H222K CC73ECH1H221J	CHIP C 0.22UF K CHIP C 470PF J CHIP C 68PF J CHIP C 2200PF K CHIP C 220PF J
C101 C102	CK73EB1H221K CK73FB1C104K	CHIP C 220PF K CHIP C 0.10UF K
CN1 CN2	E40-9536-05 E40-9339-05	FLAT CABLE CONNECTOR FLAT CABLE CONNECTOR
L1 X1 X2	L40-1001-31 L78-0620-05 L78-0528-05	SMALL FIXED INDUCTOR(10UH) RESONATOR RESONATOR
R1 R2 R3 R4 R5	RK73FB2A243J RK73FB2A183J RK73FB2A154J RK73FB2A155J RK73FB2A910J	CHIP R 24K J 1/10W CHIP R 18K J 1/10W CHIP R 150K J 1/10W CHIP R 1.5M J 1/10W CHIP R 91 J 1/10W
R6 R7 R8 R9 R10 ,11	RK73FB2A154J RK73FB2A155J RK73EB2B4R7J RK73EB2B100J RK73FB2A912J	CHIP R 150K J 1/10W CHIP R 1.5M J 1/10W CHIP R 4.7 J 1/8W CHIP R 10 J 1/8W CHIP R 9.1K J 1/10W
R12 R13 R14 ,15 R16 R17	RK73FB2A562J RK73FB2A683J RK73FB2A824J RK73FB2A223J RK73FB2A393J	CHIP R 5.6K J 1/10W CHIP R 68K J 1/10W CHIP R 820K J 1/10W CHIP R 22K J 1/10W CHIP R 39K J 1/10W
R18 R19 R20 R21 R31	RK73FB2A392J RK73FB2A333J RK73FB2A104J RK73FB2A224J RK73FB2A102J	CHIP R 3.9K J 1/10W CHIP R 33K J 1/10W CHIP R 100K J 1/10W CHIP R 220K J 1/10W CHIP R 1.0K J 1/10W
R32 R33 R34 R35 R36	RK73FB2A104J RK73FB2A155J RK73FB2A333J RK73FB2A104J RK73FB2A111J	CHIP R 100K J 1/10W CHIP R 1.5M J 1/10W CHIP R 33K J 1/10W CHIP R 100K J 1/10W CHIP R 110 J 1/10W
R37 R38 R39 R41 R42	RK73FB2A471J RK73FB2A224J RK73FB2A102J RK73FB2A101J RK73FB2A104J	CHIP R 470 J 1/10W CHIP R 220K J 1/10W CHIP R 1.0K J 1/10W CHIP R 100 J 1/10W CHIP R 100K J 1/10W
R43 R44 R45 R46 R47	RK73FB2A101J RK73FB2A102J RK73FB2A103J RK73FB2A102J RK73FB2A103J	CHIP R 100 J 1/10W CHIP R 1.0K J 1/10W CHIP R 10K J 1/10W CHIP R 1.0K J 1/10W CHIP R 10K J 1/10W
R48 -50 R51 R52 R53 R54	RK73FB2A472J RK73FB2A101J RK73FB2A104J RK73FB2A101J RK73FB2A104J	CHIP R 4.7K J 1/10W CHIP R 100 J 1/10W CHIP R 100K J 1/10W CHIP R 100 J 1/10W CHIP R 100K J 1/10W
R55	RK73FB2A101J	CHIP R 100 J 1/10W

CD PLAYER UNIT (X32-4280-00) MECHANISM ASSY (X92-3120-00)

				MECHANISM ASSY (X92-3120-00
Ref.	No.	N e w	Parts No.	Description
R56 R57 R58 R63 R65	-61 ,64 ,66		RK73FB2A104J RK73FB2A472J RK73FB2A101J RK73FB2A101J RK73FB2A472J	CHIP R 100K J 1/10W CHIP R 4.7K J 1/10W CHIP R 100 J 1/10W CHIP R 100 J 1/10W CHIP R 4.7K J 1/10W
R67 R68 R69 R71 R72			RK73FB2A101J RK73FB2A104J RK73FB2A101J RK73FB2A752J RK73FB2A102J	CHIP R 100 J 1/10W CHIP R 100K J 1/10W CHIP R 100 J 1/10W CHIP R 7.5K J 1/10W CHIP R 1.0K J 1/10W
R73 R74 R75 R76 R77			RK73FB2A333J RK73FB2A822J RK73FB2A273J RK73FB2A512J RK73FB2A393J	CHIP R 33K J 1/10W CHIP R 8.2K J 1/10W CHIP R 27K J 1/10W CHIP R 5.1K J 1/10W CHIP R 39K J 1/10W
R78 R79 R80 R81 R82			RK73FB2A153J RK73FB2A202J RK73FB2A162J RK73FB2A273J RK73FB2A562J	CHIP R 15K J 1/10W CHIP R 2.0K J 1/10W CHIP R 1.6K J 1/10W CHIP R 27K J 1/10W CHIP R 5.6K J 1/10W
R93 R95	,92 ,94 ,96 -106		RK73FB2A561J RK73FB2A332J RK73FB2A562J RK73FB2A203J RK73FB2A203J	CHIP R 560 J 1/10W CHIP R 3.3K J 1/10W CHIP R 5.6K J 1/10W CHIP R 20K J 1/10W CHIP R 20K J 1/10W
R201	7,108 ,202 3,204		RK73FB2A681J RK73FB2A392J RK73FB2A204J RK73FB2A472J R92-2052-05	CHIP R 680 J 1/10W CHIP R 3.9K J 1/10W CHIP R 200K J 1/10W CHIP R 4.7K J 1/10W CHIP R 0 J 1/10W
W11	-13		R92-2053-05	CHIP R 0 J 1/8W
S1 S3	, 2		S68-0822-05 S68-0823-05	PUSH SWITCH PUSH SWITCH
D1 D11 IC1 IC2 IC3	, 2	*	DAN202K DAN202K AN8806SB MN662747RPH M37471M8-371FP	DIODE DIODE ANALOGUE IC MOS-IC MI-COM IC
IC4 IC5 IC6 Q1 Q2			BA6790FP TA78L05F NJM4565MD 2SA1362(Y) DTC124EK	ANALOGUE IC IC(VOLTAGE REGULATOR/ +5V) IC(OP AMP X2) TRANSISTOR DIGITAL TRANSISTOR
Q3 Q5 Q6 Q12	, 4		2SA1362(Y) DTC124EK 2SA1037K DTC124EK	TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR
				ASSY (X92-3120-00)
1 2 3	2 A 1 B 2 B		A10-4224-41 A10-4225-33 A11-0915-23	CHASSIS CHASSIS CALKING ASSY SUB CHASSIS CALKING ASSY
4 5	3B 2A		D02-0209-13 D10-3082-13	TURNTABLE PLATTER ARM

K2:KDC-7009

E4:KDC-7060R

E5:KDC-7060RY

 \triangle indicates safety critical components.

K2:KDC-7009 E4:KDC-7060R E5:KDC-7060RY

KDC-7009/7060R/RY KDC-7009/7060R/RY **PARTS LIST**

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

		arts No. werden nie						MECHANISM ASSY (X92-3120-00)
Ref. No	o. N	Parts No.	Description	Ref	. No.	N e w	Parts No.	Description
6 2 7 2 8 3	2A 2A 2A 3A 2B	D10-4038-23 D10-3083-34 D10-3084-34 D10-3087-44 D10-3092-03	ARM ASSY ARM ASSY ARM ASSY ARM ASSY SLIDER	65 66 67 68 69	1B 1B 3B 3A 2A		G01-2775-04 G01-2776-14 G01-2777-14 G02-1250-04 G01-2844-04	TORSION COIL SPRING TORSION COIL SPRING TORSION COIL SPRING FLAT SPRING EXTENSION SPRING
11 2 12 2 13 1	3B 2B 2B 1A	D10-3093-04 D10-3095-04 D10-3096-04 D10-3099-24 D10-3100-04	SLIDER ASSY SLIDER ASSY SLIDER ASSY SLIDER ASSY SLIDER ASSY SLIDER ASSY	70 71 72 73	2A 2B 2A 2A		G02-1231-04 G02-1232-14 G02-1241-24 G02-1248-14	FLAT SPRING FLAT SPRING FLAT SPRING FLAT SPRING
16 1 17 1 18 1	B B B B	D10-4003-23 D10-4004-04 D10-4006-04 D10-4007-04 D10-4008-04	LEVER LEVER ASSY LEVER LEVER LEVER LEVER	75 76 77 78 79	2A 3A 2B 3B 2A		J11-0613-13 J19-4678-13 J19-4679-24 J21-7684-03 J21-7686-03	CLAMPER HOLDER HOLDER MOUNTING HARDWARE MOUNTING HARDWARE
20 2 21 3 22 3 23 3	2A 3A 3A 3A	D10-4009-23 D10-4010-04 D10-4011-34 D10-4013-14	ARM LEVER LEVER ASSY ARM ASSY	80 81 82 83	1B 3A 3A 1A		J21-7690-03 J31-1032-04 J84-0060-05 J90-0757-22	MOUNTING HARDWARE COLLAR FLEXIBLE PRINTED WIRING BOARD GUIDE
27 3 28 3 29 3 30 3	3B 3B 3B 3B 3B	D13-1340-13 D13-1230-14 D13-1231-04 D13-1232-04 D13-1233-04	RACK (GEAR) WORM GEAR GEAR GEAR	A B C D E	2A 1B 2B 2A 3A		N09-4249-05 N09-4172-05 N09-4202-05 N38-2020-46 N82-2006-45 N19-2023-04	MACHINE SCREW (M1.7X2.5,LOCK) TAPPING SCREW (2X3.5,C94h) STEPPED SCREW PAN HEAD MACHIN SCREW BINDING HEAD TAPTITE SCREW FLAT WASHER
32 3 33 3 34 3 35 3	3B 3A 3B 3B 3B	013-1234-14 D13-1238-03 D13-1240-04 D13-1241-04 D13-1242-04	GEAR ASSY GEAR GEAR GEAR GEAR	M1 M2 PU1	3B 3B 2B		N19-2093-04 T42-0764-04 T42-0763-04 T25-0209-05	FLAT WASHER MOTOR ASSY MOTOR ASSY OPTICAL PICKUP HEAD
38 1 39 1 40 2	B B B B B B	D13-1243-04 D13-1244-04 D13-1245-14 D13-1246-04 D13-1247-04	GEAR GEAR GEAR GEAR GEAR					
43 2 45 1 46 1	2B 2B B A 3B	D13-1248-34 D13-1249-04 D14-0668-04 D14-0670-04 D14-0674-04	GEAR GEAR ASSY ROLLER ROLLER ROLLER				·	
49 3 50 1 51 1	2B 3A 1A 1A 2A	D19-0613-24 D21-2228-04 D21-2229-04 D23-0925-24 D32-0614-04	LEAD SCREW SHAFT SHAFT RETAINER STOPPER					
	B 2B	D39-0223-05 D39-0224-05	DAMPER DAMPER					
55 3	3B	F09-1246-04	SHEET					
61 3 62 3 63 3	2A 3A 3A 3A 3A	G01-2770-04 G01-2771-04 G01-2772-24 G01-2773-14 G01-2774-34	EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING					

K2:KDC-7009

E4:KDC-7060R E5:KDC-7060RY ${\underline{\smash{\wedge}}}$ indicates safety critical components.

SPECIFICATIONS

KDC-7009 FM tuner section Frequency range (Frequency step) Channel space selection Fix Usable sensitivity (S/N : 30dB) 9.3dBf (0.8μV/75Ω) Quieting sensitivity (S/N : 50dB) 15.2dBf (1.6 μ V/75 Ω) Signal to Noise ratio (MONO)70dB

AM tuner section

Frequency range (Frequency step) 530kHz~1700kHz (10kHz)	
Channel space selection fix	
Usable sensitivity (S/N : 20dB)28dBμ (25μV)	

Selectivity (dB) ≥ 80dB (±400kHz)

CD Section	
Laser diode	
Digital filter (D/A)	8 times over sampling
D/A converter	1 Bit
Spindle speed	500~200 (CLV)
Wow & Flutter	Below measurable limit
Frequency response (±1dB)	10~20kHz
Total harmonic distortion	0.01% (1kHz)
Signal to Noise ratio (1kHz)	93dB
Dynamic range	93dB
Chanel separation	

Audio section

Preout level (mV)/Load (CD/CD-CH)	
Unbalanced	
Preout impedance	600Ω
Amp power	
Max	40W × 4
Full bandwidth (at less than 1% THD)	22W x 4
Tone action	
Bass	100Hz±10dB
Troble	10kH=+10dP

General

Current consumption	10A
Installation size (W x H x D)	182 x 53 x 165 (mm)
7-3/16 x	2-1/16 x 6-1/2 (inch)
Weight	(4.4lbs) 2.0kg

Operating voltage 14.4V (11~16V allowable)

KDC-7060R

FM tuner section

Frequency range (Frequency step)

Frequency range (Frequency step)
Quieting sensitivity (S/N : 46dB)
Frequency response (±3.0dB)
Signal to Noise ratio (MONO)
Selectivity (DIN) (dB)
Stereo separation (1kHz)
MW (AM) tuner section
Frequency range 531kHz~1611kHz (9kHz)
Usable sensitivity (S/N : 20dB)25μV
LW tuner section
Frequency range (Frequency step)
Usable sensitivity (S/N : 20dB)45 μV
CD section
Laser diode
Digital filter (D/A)
D/A converter
Spindle speed
Wow & Flutter Below measurable limit
Frequency response (±1dB) 10~20kHz
Total harmonic distortion
Signal to Noise ratio (1kHz)
Dynamic range93dB
Chanel separation 85dB
Audio section
Preout level (mV)/Load (CD/CD-CH)
Unbalanced
Preout impedance
Max 40W x 4
DIN45324.+B=14.4V
Tone action
Bass
Treble
TOKITEE TOUB
General

KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

KENWOOD CORPORATION

KENWOOD SERVICE CORPORATION
P.O. BOX 22745, 2201 East Dominguez Street, Long Beach, CA90801-5745, U.S.A. KENWOOD ELECTRONICS CANADA INC. 6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

KENWOOD ELECTRONICS LATIN AMERICA S.A. P.O. BOX 55-2791, Piso 6, Plaza Chase, Cl. 47 y, Aquilino de la Guardia, Panama, Republic of Panama

KENWOOD ELECTRONICS BRASIL LTDA. Avenida Indianópolis, 628, 04062-001 Planalto Paulista, São Paulo-SP-Brasil KENWOOD ELECTRONICS UK LIMITED
Kenwood House, Dwight Road, Watford, Herts, WD1 8EB United Kingdom
KENWOOD ELECTRONICS DEUTSCHLAND GMBH
Rembrücker-Str. 15, 63150 Heusenstamm, Germany

KENWOOD ELECTRONICS FRANCE S.A. 13, Boulevard Ney, 75018 Paris, France

KENWOOD ELECTRONICS BELGIUM N.V. Mechelsesteenweg 418, B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS ITALIA S.p.A. Via G. Sirtori 7/9, 20129 Milano, Italy

KENWOOD IBÉRICA S.A.

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD. (A.C.N. 001 499 074) 8 Figtree Drive, Australia Centre, Homebush, N.S.W. 2140, Australia

Operating voltage 14.4V (11~16V allowable) Current consumption 10A Installation size (W x H x D) 182 x 53 x 165 (mm)

KENWOOD & LEE ELECTRONICS, LTD. Unit 3712-3724, Level 37, Tower 1, Metroplaza, 223 Hing Fong Road, Kwai Fong, N.T., Hong Kong

KENWOOD ELECTRONICS GULF FZE P.O. Box 61318, Jebel Ali, Dubai, U.A.E.

KENWOOD ELECTRONICS (THAILAND) CO., LTD. 573/111 Soi Ramkhamhaeng 39, Ramkhamhaeng Road, Wangthonglang, Bangkapi, Bangkok, 10310 Thailand

KENWOOD ELECTRONICS SINGAPORE PTE. LTD.
1 Genting Lane #07-00, Kenwood Building, Singapore, 349544

KENWOOD ELECTRONICS (MALAYSIA) SDN BHD
#4.01 Level 4, Wisma Academy, Lot 4A, Jalan 19/1, 46300 Petaling Jaya selangor Malaysia